Quick Start Guide

TITAN 5100 5G Window CPE

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Watch a quick setup video

https://glob-tel.com/quick-start-guides/titan-5100-quick-start-guide

LET'S GET STARTED

Thank you for selecting the Titan 5100 to deliver cellular connectivity for your home or office. Choose Basic Setup for quickest installation or Guided Setup to ensure your device is placed in the highest performing location.

What's in The Box

Device	4 Suction Cups	3 Adhesive Strip	Pole Mount Bracket/Clamp 4 Screws	Wall Mount Bracket 4 Screws	PoE Adapter Power Cord	Ethernet Cable Waterproof Seal	Tamper-proof Cover	Quick Start Guide

BASIC SETUP

Your device is ready to go out of the box once it's powered up and placed in the best spot in your location.

1 **Install the SIM card and connect the network cable**
Open the SIM card cover, insert the SIM card and connected the ETH cable.

2 **Find a window to mount your device**
For best performance select an open location on an upper floor/high off the floor with no interference from other electrical devices like microwaves.

3 **Connect cables on your device**
Your device will automatically power on and connect to the internet. This can take several minutes.

1 Connect one end of your Ethernet cable to your device and the other to the PoE adapter's PoE port. (The device will not work if connected to the LAN port.)

2 Connect your power cord to the back of the PoE adapter and plug the other end of the power cord into a wall outlet.

4 **Attach suction cups and test performance**
Attach suction cups to the back of the device and place the device on a window, pressing firmly on device to ensure it's securely attached to window. To try another location carefully remove device from window. It may help to pull the corners of each suction cup up one at a time.

5 **Fixing the equipment in the best spot**
Once you've found your best-performing location fix the equipment in place. Clean the window with alcohol wipe and let dry. Use suction cups or adhesive strips to secure device to the window.

Your TITAN5100 is now up and running. Go to Mobile Guided Set up and Device Management on the next page to connect and manage your Wi-Fi network.

MOBILE GUIDED SETUP AND DEVICE MANAGEMENT

For a more detailed step-by-step setup guide and to access simple features to manage your device scan this QR code to access the device directly.

Access Guided Setup and Management

Device must be powered on prior to scanning QR code.

1 **Use mobile device to scan QR code**
QR code can also be found on the front of the PoE adapter. By scanning the QR code, your mobile device will automatically connect to the WIFI network for device management. The mobile device browser will automatically access the management page of the current device.

Set up and manage your TITAN5100 cellular modem
1 Connect the ethernet cable between the Titan 5100 and the PoE port here. (Device will not work if plugged into LAN port.)
2 Connect the power cord to the power port here and a wall outlet.
3 Scan the QR code to set up and manage your device. When prompted, enter your user name and device password below.
Model: GSG-X62W Device URL: XX.X.X.X
UPC#: 198715328066 User name: XXXXXXXX
FCC ID: S3XXXXXXX Password: XXXX
S/N: GLOBAL12XXXXXX WiFi SSID: XXXX
IMEI: 35639209XXXXXX WiiFi PWD: GTXXXXXX

2 **Enter user name and password**
Your user's name and password are located on the sticker attached to the PoE adapter.

3 **Follow device setup instructions**
Select device setup and follow instructions to test performance and place the device in the best location. Your WiFi username and password are located on the sticker attached to the PoE adapter.

4 **Ongoing device management**
Rescan QR code whenever you need to come back to manage your device, test performance, and conduct basic troubleshooting.

No access to a mobile device? Connect your PC to the device using the LAN port and open a web browser. Type: http://192.168.0.1 in the address bar. In the pop-up window, enter the device username and password from the label on the PoE adapter to log in.

MOUNTING OPTIONS

You can install and fix the equipment in the desired area.

Clamp Poll Mounting Option

Bracket Wall Mounting Option

Window Mounting Option

Suction Cap Window Mounting Option